8th International Workshop on Anomalies in Hydrogen/Deuterium Loaded Metals, Oct13-18, 2007,Catania, Italy

Changes in Surface Layer Impurities of Pd Due to Heat and/or *Deuterium*-Permeation Treatments and Their Influence on *Deuterium* Permeability

T. Hioki, J. Gao, N. Takahashi and T. Motohiro

TOYOTA Central R & D Laboratories, Inc.




Outline


- **1. Introduction**
- 2. Change of elemental concentration on Pd by heat treatment
 - Annealing in vacuum, in air
 - Sulfur and Oxygen
- 3. Change of elemental concentration on Pd with D2 permeation
 - Sulfur and Oxygen
- 4. Improving the rate of D2 permeation through Pd by heat treatment




D2 Permeation through Pd




Y.Arata and Y.Zhang (ICCF12)



TOYOTA CRDL, INC.



Example of D2 permeation rate vs time





6 **D2 Permeation through Pd** For high permeation rate **D**2 gas \bigcirc \bigcirc \bigcirc \bigcirc **Dissociative Adsorption** \bigcirc \bigcirc \bigcirc (front surface) & **Recombination (back surface)** are to be active Pd Vacuum evacuation Both surfaces are to be clean

→ Pd is annealed in air at \ge 300°C as a pretreatment to remove organic carbon


TOYOTA CRDL, INC.

Annealing condition before D2 Permeation






Effect of heat treatment on D2 permeation




Elemental concentration on the surface of Pd after heat treatments (by XPS)




Vac anneal \Rightarrow high S concentration at the surface Air anneal \Rightarrow low S concentration \Rightarrow initial high permeability


TOYOTA CRDL, INC.



Initial Permeation rate & surface S concentration




Change of surface elemental concentration *due to D2 permeation*



Increase of S is remarkable for the air- annealed samples


TOYOTA CRDL, INC.


Reduction of PdOx by D2 Permeation






Surface segregation of S by D2 permeation





D2 permeation rate vs time for Pd heat-treated in vacuum & in air



TOYOTA CRDL, INC.

Summary (1)

Vacuum annealing

- 1. By annealing in vacuum at high temperatures, S is segregated to the surface
- 2. Due to the segregated S, D2 permeation rate is greately decreased (S poisoning of Pd)

Air annealing

3. Annealing in air at high temperatures oxydizes Pd but removes S from the surface



Summary (2)

D2 permeation

- 4. With D2 permeation, oxydized Pd is reduced to metallic Pd at a temperature as low as 343K (70℃)
- 5. With D2 permeation, S impurity in Pd bulk is segregated to the surface at a temperature as low as 343K (70 $^{\circ}$ C)

Improving D2 permeation rate

6. By combining vacuum- and air-annealing, a high permeation rate is obtained and its degradation is comparatively small.

